



EYEWASH PLAN

1	2	3	4
Determine type of substance	Select appropriate eye wash and rinse	Continue rinsing with Plum Eyewash	Rinse as directed
Foreign substances (e.g. dust, dirt, metal, wood, splinters, etc.)	Plum Eyewash	Plum Eyewash	Rinse until substance is removed
Acid	pH Neutral	Plum Eyewash	Rinse for about 2 minutes using pH Neutral and continue using Plum Eyewash until you reach a doctor or an emergency room
Alkali	pH Neutral	Plum Eyewash	Rinse for about 2 minutes using pH Neutral and continue using Plum Eyewash until you reach a doctor or an emergency room
Other chemicals (e.g. solvents or oils)	Plum Eyewash	Plum Eyewash	Rinse until you reach a doctor or an emergency room



pH Neutral



Plum Eyewash



Plum Eyewash is easy to use if an accident happens



Turn the eye cup in the direction of the arrow until the seal breaks



Lean back, squeeze the bottle and rinse



The eye can also be rinsed while you lean forward - by squeezing the bottle gently

IMPORTANT!

Always ensure the eye wash liquid hits the eye with a soft and even flow. In case of concurrent injury on both eyes, use DUO for rinsing both eyes simultaneously.